Sapphire

INSTALLATION INSTRUCTIONS
Decorative ceiling fan (fan light)

MODEL:
FM-48060.DC - FM-48111.DC
FM-48068.DC - FM-48208.DC
FM-48068.DC - FM-48333.DC
FM-48748.DC - FM-48333.DC

Decorative ceiling fan

Notes
- Only a suitably professional electrician must be hired for installation.
- A ceiling fans must not be installed on switch boxes or light level wiring cache. It must be ensured that the hanging junction can withstand at least 50kg weight.
- Before installation, switch off the mains electricity supply at the point of the power that.
- Ensure that all electrical connections are tight and that the fan is secured firmly, and the ground wire must be grounded.
- If the fan is controlled by a wall-slung, the fan blades should be mounted at least 2.3 meters from the ground level and at least 0.3 meters from the wall. Do not bend the fan blades and blades racks during installation. Keep the fan blades and blades racks away from the sharp objects. Do not insert any foreign objects into the rotating fan blades.
- If the fan is mounted on a sloping ceiling, the ceiling bracket 3mm must be installed at the power supply to ensure the blades have adequate clearance.
- If the electrical components are damaged, the manufacturer or its service center must provide the replacement parts. Do not disassemble the motor housing and the motor cover. Do not lubricate it. Customers who purchase multiple units of the same model must open a box to install one unit and cancel out the accessories of several units together for mount installation.
- Do not use the fan if the blades are bent or damaged. Do not insert objects or fingers into the blades when the power is on. Do not touch the blades while they are moving.
- Note: This is a class I product and must be connected to the earth supply wire installation.

WARNING: ELECTRIC SHOCK HAZARD

Must read before installing the fan
1. The ceiling fan does not have
2. Switch off the power supply at the fan power circuit contact.
3. Check if the fan power voltage is correct.
4. The ceiling fan makes noise.
5. Check if the blades are properly tightened.
6. Check if there is any foreign object on the ceiling fan.

Preparation of tools before installation

1

Please read this instruction manual before installing the product and keep it.

Product installation instructions

Packing list

Serial number	Name	Quantity
1	Hanging chick	1 PCS
2	Hanging frame	1 PCS
3	Hanging rod	1PCS
4	Small package	1 PCS
5	Lamp body + light source	1 PCS
6	Blade	1 PCS
7	Remote control	1 PCS
8	Accessory package	1 PCS
9	Instructions	1 PCS

2

Basic parameters
1. Voltage: 180-265V 50/60Hz
2. Power: Power: power: 18W
3. Speed + Color changer: transmit+ color temperature
4. Remote control: 2.4G RF
5. Fan blade material: ABS + Iron
6. Motor material: Pure copper wire winding and high-quality silicon steel sheet, high efficiency, low noise, and long life
7. Control method: Remote control
8. Diameter: 42CM
9. Warranty: 1YR

Notes
1. The receiver is divided into input and output. It is strictly forbidden to swap the input and output lines.
2. The working voltage of this product: AC 180V-265V
3. If the fan is used outdoors, the fan must be turned on to effectively control it.
4. Please connect the wires according to the wire color and the instructions on the sleeve.
5. Please make sure that the power supply is turned off before the battery is installed (carefully pay attention to the positive and negative poles of the battery). The indicator light of the handle control button will flash once to indicate a successful connection.

3

6. Use an 8 mm insert drill bit two holes in the top of the cement.
7. Clean the hole.
8. Tighten the expansion screw (note the flat size of the hole should not be too large).
9. Remove the screw and the washer.
10. Narrow the screws to load the top fan.

Product installation instructions

INSTRUCTION PROCEDURES
STEP 1 (See Diagram 1.)

1) Refer to the diagram below the rubber wheel and plastic plug from both side of the hanging bracket.

2) Loosen two set screws on the bracket and remove the canopy from the downrod into the downrod support.
Thread the electrical wires and the earth wire through the hole in the downrod.
Align the Clevis Pin holes in the Downrod with the holes in the Downrod Support. Be sure to align the holes so that the Clevis Pin will pass through the hole near the end of the Clevis Pin until the curved portion of the Hairpin snaps around the Clevis Pin. Bend the Hairpin to secure the Clevis Pin. Place the receiver of remote control on the top canopy.

Diagram 1

3) Hang the fixture wheel on the bracket.
4) Lift the motor bracket to the rubber wheel with the previously loosened bolt, washer nut and fit gasket.

5

NOTE:
1. Installation without proper procedures as above mentioned might result to fan loosening or falling.

WARNING:
1. Installation without proper procedures as above mentioned might result to fan loosening or falling.

6

Product installation instructions

7

Power connection
1. Connect the receiver with a certain p:ender than 18W must be installed at the power end of the fan (prepared by the user).
2. Connect the receiver and wiring method
3.Open the mask and ensure that the controller of the lamp body is connected correctly and firmly.
(4) Connect the blue and brown wires at the tail of the fan lamp and the 220V AC neutral and live wire.

Calling fan and lamp operation
Remote control operation: Please refer to the remote control instructions for speed switch (one, medium, high fan gear), the direction of wind, light switch and brightness and three colors of functions.

8

Product installation instructions

The specific operation

- Turn on the power, connect the receiver to the lower-side power turning off.
- Fan with memory function, fan runs when power is turned on.
- Fan with remote control, you can use it as a wall switch to open power on and the fan will normally run, and the fan will run in the last state when it was turned off.
- Turn off the fan with the "-" button on the remote control, and turn it on again to restore the previous memorial. The "+" button is the same as "-" button, the fan runs at the highest frequency.
- Forward and reverse modes have a memory function to memorize the last state before power off.

Note: Please check the battery when the remote control cannot be effectively controlled, and remove and install the battery after changing.

Matters needing attention:
- Please read the instruction manual carefully before operating the convenience of the cover and ceiling.
- Receiver and inputs and outputs are strictly prohibited from adjusting input and output ports.
- Do not use the fan if the blades are bent or damaged.
- Do not insert objects or fingers into the blades when the power is on. Do not touch the blades while they are moving.
- Please do not add lubricating oil to the ceiling fan motor, because the motor bearing comes with lubricating oil.

Calling fan failure and solution
Safety precautions:
1. Check whether the fuse of the external power supply circuit of the fan is Blown, and whether the automatic protection switch is tripped.
2. Check whether the power supply is in short circuit or disconnected in the open.
3. Check whether the power supply voltage is seriously lower than the rated voltage of the ceiling fan? Generally, it should not be lower than 180V.
4. Check whether the power supply of the ceiling fan is fixed or has poor contact.

Note: If the above three checks still cannot eliminate the fault, please contact the professional electrical fan maintenance personnel of the dealer for repair.

Safety precautions:
1. Make sure the ceiling fan is not severely impacted before installation.
2. Make sure the ceiling fan is not severely impacted before installation.
3. Make sure the ceiling fan is not severely impacted before installation.
4. A 6-hour trial period is allowed for new ceiling fans. After the trial period, the noise of new ceiling fans will disappear.
5. Fans with electronic control or wooden ceilings, steel structures or prefabricated panels are less prone to noise.
6. Check whether the motor cover is loose.
7. Check whether the light switch is damaged, the wire ends are loose, or the wire terminals are not connected.
8. Check whether the replaceable light source is burned out.

Ceiling Fan Troubleshooting Solutions & Common Problems

Can't start	1. Check whether the fuse of the external power box of the ceiling fan is blown, whether the automatic protection switch is tripped or whether the power is off.
	2. Check whether the voltage is obviously lower than the rated voltage of the ceiling fan.
	3.Check whether the internal wiring of the ceiling fan is loose or has poor contact.
Noise	1. Ensure the ceiling fan is not severely impacted before installation
	2. Make sure that the motor bearing and the gear are lubricated correctly and the hanging pipe connection is tight.
	3.The new ceiling fan allows a 6-hour trial period after the fan is installed. After the trial period, the noise of the new ceiling fan will disappear.
	4.It is normal that installing a stainless steel ceiling, steel, other prefabricated panels, etc. due to the resonance of the ceiling.
The lamp is defective	1. Check whether the connection wire of the lamp is loose.
	2. Check whether the light bulb is damaged. Replace with a new bulb of the correct size.
Fan wobble	1. Check whether the fan blade spacing is balanced.
	2. Check whether the hanging bracket is loose.
	3. Check if the screws of the fuse base is loosen.
	4. Check whether the screw of the blade clamped to the motor is locked.

9

10

Copyright © Sapphire Lighting GmbH. All rights reserved. Reproduction, distribution or publication of this document is prohibited without the prior written consent of Sapphire Lighting GmbH.